



HELPFUL HINT:  
 WEDGE BEHIND BEVELED BLOCK  
 CAN BE A GOOD PLACE TO RUN  
 ELECTRICAL WIRES AFTER  
 SCREWS ARE IN PLACE.

PBS-301

*BEVELED BLOCK WALL/ROOF*  
**FORCE PANELS**

